

BC1200 SIGMA SPORT BICYCLE COMPUTER



The BC1200 is set up to switch back and forth between 2 bicycles. Please make sure the correct bicycle is showing before you begin your ride.

I. TO SET CLOCK

- Press bottom button until clock appears at the bottom of the screen.
- Turn computer over and press and hold the right indented gray set button
- (S) for 5 seconds or until clock flashes.
- Press top button until hour is reached.
- Press bottom button to move to minutes.
- Press top button until desired number is reached.
- Press bottom button to move to single minutes.
- Press top button until desired single minute is reached.
- Turn computer over and press right indented gray set button (S) for 1 second to set.

II. TO SET MPH/KMH, LANGUAGE, AND WHEEL SIZE 1

- Make sure computer is on BIKE 1.
- Press bottom button until CLOCK or TOTALODO is not displaying on screen.
- Turn computer over and press and hold the indented gray set button for 5 seconds or set language flashes.
- Press top button to switch select: Deutsch(German), English, Francais(French), Italiano(Italian), Espanol(Spanish), Svensk(Swedish), or Hollands.
- Press bottom button to accept & select KMH/MPH.
- Press top button until your selection is reached.
- Press bottom button to select & move to wheel size.
- (Consult chart or figure yourself by measuring from the top of the tire to the ground in inches.) Measurement
 $X 25.4 \times 3.14 / 1.61 = ws$ (/ is divided by)
- Press top button to advance numbers.
- Press bottom button to make 2nd digit flash.
- Press top button to advance numbers.
- Press bottom button to make 3rd digit flash.
- Press top button to advance numbers.
- Press bottom button to make 4th digit flash.
- Press top button to advance numbers.
- Press indented right set button on back for one second to store.

III. TO SET WHEEL SIZE 2

- Press gray indented I / II button on back to switch to bike 2.
- Press bottom button until CLOCK or TOTALODO is not displaying on screen.
- Press and hold gray indented set button on back for 5 seconds to make II and first number flash.
- Press top button to advance numbers.
- Press bottom button to make 2nd digit flash.
- Press top button to advance numbers.
- Press bottom button to make 3rd digit flash.
- Press top button to advance numbers.
- Press bottom button to make 4th digit flash.
- Press top button to advance numbers.
- Press indented gray set button on back for one second to store.

IV. TO SET TOTALODO (ONLY IF YOU WOULD LIKE TO PROGRAM MILES PREVIOUSLY RIDDEN)

- Press bottom button until TOTALODO is showing.(This will program miles previously ridden.)
- Press gray indented set button on back for 5 seconds to make flash.
- Press top button to advance numbers and bottom button to move to the next number.
- Press indented gray set button for 1 second to store.

V. TRIP COUNTER (MOSER GUIDE) TRIP UP – (to count up as normal)

- Press bottom button until TRIP UP or TRIPDOWN appears.
- Press top and bottom buttons simultaneously, then release. SET will flash.
- Press top button to set TRIPUP.
- Press bottom button to select with first number flashing.
- Press top button to advance numbers & bottom button to move to next flashing number.
- Press top and bottom buttons simultaneously to lock in.

VI. TRIP COUNTER (MOSER GUIDE) TRIP DOWN – (to count down to destination)

- Press bottom button until TRIP UP or TRIPDOWN appears.
- Press top and bottom buttons simultaneously, then release. SET will flash.
- Press top button to set TRIPDOWN.
- Press bottom button to select with first number flashing.
- Press top button to advance numbers & bottom button to move to next flashing number.
- Press top and bottom buttons simultaneously to lock in.

VII. VI To Reset modes DIST/DAY, RIDETIME, AVGSPEED, MAXSPEED, or STPWATCH individually, press bottom button until desired mode is reached. Press the top left button for 2 seconds to reset to zero. Continue to hold top left button to reset all.

DIST/DAY – Will record distance traveled. Reset by pressing top button until RESET DIST/DAY stops flashing. (automatically resets after 999.99 miles)

RIDETIME – Auto start/stop stopwatch that shows actual time ridden.

AVGSPEED – Shows average speed only when moving. It will continue with previous numbers until reset. Can be reset by pressing top button until RESET AVGSPEED stops flashing.

- ↑ Above average speed during the ride.
- ↓ Below average speed during the ride.

STPWATCH – Stopwatch function can be controlled by pressing top button to start. Press again to stop. Press top button and hold until RESET STPWATCH stops flashing to reset to zero.

MAXSPEED – Maximum speed reached while riding. Can be reset by pressing top button until RESET MAXSPEED stops flashing.

CLOCK – Current time.

TOTALODO – Total distance for bike 1 and bike 2 combined. (automatically resets after 99999 miles)